


Chapter 5 System Parameter Settings

In the EB8000, select menu [Edit] / [System Parameters...] and the System Parameter Settings dialog display as follows:



System Parameter Settings are divided into seven parts: **[Device]**, **[Model]**, **[General]**, **[Security]**, **[Font]**, **[Extend Memory]** and **[Printer Server]**, which are introduced respectively in this chapter.

[Device]

[Device] parameters determine all of the characteristics of each device controlled by a HMI. These devices include PLC, remote HMI and PC. When open a new *.mtp file, a default device: “Local HMI” is in the table. That is to say the device table must have a “Local HMI” at least, and it is used to identify current HMI.

The procedure to create a new device as follow:

(1) How to control a local PLC




So-called “local PLC” means a PLC is connect to local HMI directly. To control a local PLC should add this type of device first. Click [New...] and the following [Device Properties] dialog display. Correctly fill in all of the properties as required.



Here an example local PLC is MITSUBISHI FX0n/FX2

The screenshot shows the 'Device Properties' dialog box for a MITSUBISHI FX0n/FX2 PLC. The dialog is titled 'Device Properties' and contains the following fields and options:

- Name: MITSUBISHI FX0n/FX2
- Device type: HMI, PLC
- Location: Local (dropdown menu), Settings ...
- PLC type: MITSUBISHI FX0n/FX2 (dropdown menu), V.1.00, MITSUBISHI_FX0N.so
- PLC I/F: RS-485 4W (dropdown menu), PLC default station no.: 0
- COM: COM1 (9600,E,7,1), Settings ...
- Use broadcast command
- Interval of block pack (words): 5 (dropdown menu)
- Max. read-command size (words): 32 (dropdown menu)
- Max. write-command size (words): 32 (dropdown menu)
- Buttons: OK, Cancel

Each of settings is introduced as follows:

Name	The name of device
HMI or PLC	Select [PLC] for this case
Location	[Local] or [Remote] can be selected. Select [Local] for this case
PLC type	Select the type of PLC. Select MITSUBISHI FX0n/FX2 for this case
PLC I/F	<p>Four PLC interfaces are available: [RS-232], [RS-485 2W], [RS-485 4W], and [Ethernet].</p> <p>If the interface is [RS-232], [RS-485 2W], or [RS-485 4W], click [Settings...] and then [Com Port Settings] dialog display as below. User should correctly set the COM port communication parameters.</p>  <p>[Timeout] HMI will pop up window no. 5, the “PLC No Response” message once communication interrupts over this setting.</p> <p>[Turn around delay] Before HMI sending command to PLC, this setting will delay the command. If no specific request, the default setting is 0.</p> <p>If the interface is [Ethernet], click [Settings...] and then [IP Address Settings] dialog display. User should correctly set IP address and Port No. of the PLC.</p>

	
<p>PLC default station no.</p>	<p>When contents of device address is not included station no., EB8000 will use this default setting for PLC station no. Besides, PLC station no. can put in device address directly, for example, 1#20</p>  <p>1 means PLC station no, and must to more than 0 and less than 255. 20 means PLC address, the # sign is to separate station no. and address.</p>
<p>Use broadcast command</p>	<p>For example, the value as 255 and when on device address set 255#20, the HMI will send command to PLC merely and ignore that any response from PLC.</p>
<p>Interval of block pack (words)</p>	<p>If the interval of read out address between different commands is less than this value, these commands can be combined to one. But combination won't function if this value as 0. For example, if the value as 5, when read out a word from LW3 and 2 words from LW6 respectively, because the interval of addresses between LW3 and LW6 is less than 5, these two commands can be combined to one. For that the contents of combination command becomes 5 consecutive words from LW3 (read out from LW3~LW7). Note: Max. combination command must less than [Max. read-command size].</p>
<p>Max. read-command</p>	<p>The Max. data size to be read out from device at one time.</p>

size (words)	
Max. write-command size (words)	The Max. data size to be wrote in to device at one time

After every setting is completed, a new name “Local PLC” device is list on the table.

Device list :


No.	Name	Location	Device type	Interface	I/F Protoc
Local HMI	Local HMI	Local	MT8121T (800 x 600)	Disable	N/A
Local PLC 1	MITSUBISHI FX0...	Local	MITSUBISHI FX0n/...	COM1 (9600,E,7,1)	RS485 4W

(2) How to control a remote PLC




So-called “remote PLC” means a PLC is connect to a remote HMI. To control a remote PLC should add this type of device. Click [New...] and the following [Device Properties] dialog display. Correctly fill in all of the properties as required.

Here an example remote PLC is SIEMENS S7/200



Each of settings is introduced as follows:

<p>Location</p>	<p>Select [Remote] in this case and set the IP address of the remote HMI which connected SIEMENS S7/200 PLC. Click [Settings...] to set the IP address of the remote HMI</p> 
<p>PLC Type</p>	<p>Select SIEMENS S7/200 in this case</p>
<p>PLC I/F</p>	<p>This setting is depends on what interface the remote PLC used</p>
<p>COM</p>	<p>The setting is depends on what COM port the remote PLC used</p>
<p>PLC default station no.</p>	<p>The setting is depends on what the remote PLC used</p>

After every setting is completed, a new name “Remote PLC” device is list on the table.

Device list :

No.	Name	Location	Device type	Interface
Local ...	Local HMI	Local	MT8121 T (800 x 600)	Disable
Local ...	mitsubishi FX0n/FX2	Local	mitsubishi FX0n/FX2	COM1 (9600,E,7,1)
Remo...	SIEMENS S7/200	Remote(IP:192.168.1...	SIEMENS S7/200	COM1 (9600,E,8,1)

(3) How to control a remote HMI



So-called “remote HMI” means through network, local HMI or on PC run on-line simulation to control remote HMI. To control a remote HMI should add this type of device. Click [New...] and the following [Device Properties] dialog display. Correctly fill in all of the properties as required.

Device Properties

Name : Remote HMI


HMI PLC

Location : Remote Settings ... IP : 192.168.1.11 (Port = 8000)

Interval of block pack (words) : 5

OK Cancel

Each of settings is introduced as follows:

HMI or PLC	Select [HMI] for this case
Location	Select [Remote] in this case and click [Settings...] to set IP address of remote HMI and Port no. The port no. of remote HMI and local HMI must be same 

After every setting is completed, a new name “Remote HMI” device is list on the table.

No.	Name	Location	Device type	Interface	I/F ...	St...
Local...	Local HMI	Local	MT8xxx	N/A	N/A	N/A
Local...	MITSUBISHI F...	Local	MITSUBISHI F...	COM1(96...	RS4...	0
Rem...	SIEMENS S7/200	Remote(IP:192.168.1.10, P...	SIEMENS S7/2...	COM1(96...	RS4...	2
Rem...	Remote HMI	Remote(IP:192.168.1.11, P...	MT8xxx	Ethernet	TC...	N/A

[Model]

[Model] tab parameters determine the settings of HMI model, timer source and printer.

System Parameter Settings

Device Model General Security Font Extended Memory Printer Server

HMI model : MT6056T/MT8056T (320 x 234)

HMI station no : 0

Port no. : 8000 (used as MODBUS server's port no.)

Timer

Clock source : External device

PLC name : Local HMI

Device type : LW

16-bit Unsigned

Address : 0 System tag Index register

Printer

Type : SP-M, D, E, F

COM : COM 3

Baud rate : 19200 Data bits : 8 Bits

Parity : None Stop bits : 1 Bit

Pixels of width : 100 pixel(s) Screen hard copy scale : 100%

* 100 pixels (for 1610 type) or 220 pixels (for 2407, 4004 type)

Storage space management

History data space 4.0M Max. XOB file size 8.0M

*Hint : If change storage space, please reset HMI's data logs and event logs.

HMI model

Select current HMI model as illustration below.

MT6056T/MT8056T (320 x 234)

MT6056T/MT8056T (320 x 234)

MT6070T/MT8070T (480 x 234)

MT6104T/MT8080T/MT8104T (640 x 480)

MT8121T (800 x 600)

MT8104X (640 x 480)

MT8104XH/MT8121X (800 x 600)

MT8150X (1024 x 768)

MT6070i/8070i (480 x 234)

MT8070iH/MT6100i/MT8100i (800 x 480)

If on designing time to change the HMI model, user also can resize pop-up window and objects.


	
HMI station no.	Set the no. of HMI station. If no particular purpose, select default
Port no.	Set the port no. for HMI. It is used as MODBUS server's port no. If no particular purpose, select default
Timer	<p>[Clock source]</p>  <p>Set the source of timer. The time of the timer is used by such as [Data Log], [Event Log] ...etc. objects which needs the time records.</p> <p>Selecting "HMI RTC" demonstrates the time signal comes from internal clock of the HMI.</p> <p>Selecting "External device" demonstrates the time signal comes from external device. The correct address source of time signal is necessary in this situation. Take the illustration below as an example. "TV" indicates the time from Local PLC. The contexts of 6 consecutives addresses starting from 0 show as follows:</p> <p>TV 0 -> Sec. TV 1 -> Min. TV 2 -> Hr. TV 3 -> Day TV 4 -> Month TV 5 -> Year</p>


	<p>Clock source : <input type="text" value="External device"/></p> <p>PLC name : <input type="text" value="MITSUBISHI FX0n/FX2"/></p> <p>Device type : <input type="text" value="TV"/></p> <p><input type="text" value="16-bit Unsigned"/></p> <p>Address : <input type="text" value="0"/></p> <p>Address format : ddd [range : 0 ~ 255]</p>
<p>Printer</p>	<p>[Type]</p> <p>To display supported printer, HP PCL Series have to use USB interface. Other printers have to use COM interface. For more details, please refer to the “MT8000 support printer”</p> <div data-bbox="518 689 1225 846"> <p>Type : <input type="text" value="HP PCL Series (USB)"/> * USB only</p> <p>Paper size : <input type="text" value="None"/> <input type="text" value="SP-M, D, E, F"/> <input type="text" value="EPSON ESC/P2 Series"/> <input type="text" value="HP PCL Series (USB)"/></p> </div> <p>Using COM port to connect printer has to set the accurate parameters. When choose SP-M, D, E, F, the pixels of width has to set accurate, this setting can not exceed printer’s default setting, otherwise will cause the printing to fault.</p> <div data-bbox="518 1077 1369 1368"> <p>Type : <input type="text" value="SP-M, D, E, F"/></p> <p>COM : <input type="text" value="COM 3"/></p> <p>Baud rate : <input type="text" value="19200"/> Data bits : <input type="text" value="8 Bits"/></p> <p>Parity : <input type="text" value="None"/> Stop bits : <input type="text" value="1 Bit"/></p> <p>Pixels of width : <input type="text" value="100"/> pixel(s) Screen hard copy scale : <input type="text" value="100%"/></p> <p>* 100 pixels (for 1610 type) or 220 pixels (for 2407, 4004 type)</p> </div>
<p>Storage space management (T series support)</p>	<ul style="list-style-type: none"> ● Manages the 12MB of combined Project and History data memory space. This allows smaller projects to have more internal memory for History Data or bigger project to have smaller internal memory. ● Minimum Project size is 6MB; Maximum Project size is 10 MB (default is 8MB). Minimum History data size is 2MB; Maximum History data size is 6 MB (default is 4MB). ● If the Project memory is made larger, History data may be over written when downloading. It is necessary to reset HMI’s data logs and event logs if change storage space.





[General]

[General] tab parameters determine all properties related to screen operations.




<p>Fast selection button</p>	<p>The settings of all attributes for fast selection window which is designated as window number 3.</p> <p>[Attribute] Enable or disable fast selection window. After selecting “Enable”, click [Settings...] to set the attributes of the button including color and text.</p> <p>[Position] Select the location of the fast select button. If “Left” is chosen, the button will show up at the corner of the left-bottom; if “Right” is chosen, the button will show up at the corner of the right-bottom.</p>
<p>Screen saver</p>	<p>[Back light saver] If the untouched duration of screen is equal to this value, back light will be turn off. The setting unit is minute. And back light will be turn on when the screen is touched.</p> <p>[Screen saver] If the untouched duration of screen is equal to this value, the current screen automatically switches to the assigned [Saver window no.].The setting unit is minute. If “none” value is selected, [Saver window no.] function is disabled.</p>
<p>Option</p>	<p>[Startup window no.] Select the window no. after HMI is started up.</p> <p>[Extra no. of events] The default number of events in the system is 1000. If user would like to add more records, the setting value can be modified up to 10000.</p> <p>[Common window]  </p> <p>The objects of the common window (window 4) will be with each base window. This selection determines these objects are placed on or under the objects of the base window.</p>


	<p>[Keyboard caret color] Set the color of keyboard cursor.</p> <p>[Object layout]</p>  <p>If “Control” mode is selected, when HMI operates, [Animation] and [Moving Shape] display above other kinds of objects and with no relation to the built ranking.</p> <p>If “Nature” mode is selected, the displayed sequence of objects show according to objects’ built priority.</p> <p>[RW_A enabled] Enable or disable the recipe data RW_A. After activating RW_A, an object can operate the content of RW_A .The size of RW_A is 64K.</p>
<p>Keyboard</p>	 <p>If user would like to create new keyboard, keyboard should be configured on the existing window and select [Add...] to add these windows to the list.</p> <p>Please refer to the “designing and using keypad” for more information.</p>

[Security]

[Security] tab determines the operable classes and user password. Twelve sets of password can be set. Only numeral are allowed for password and the range from 0~999999999.



On the objects, user can set operable different class is None and from class A to class F.




When setting User 1 as below, that's mean only can operable class None, A, C, and E.



About more information setting please refer to the “Object’s Security Guard”.

[Font]

[Font] tab determines the font of no-ASCII which be used on EB8000




[Fonts for no-ascii strings]

The fonts for no-ascii strings are listed above. When user used no-ascii font, and it don't listed on [Fonts for no-ascii strings] table, EB8000 will select a font which listed on table to substitute it automatically.

User also can test which no-ASCII strings of Windows can be used in HMI and add them to [Fonts for no-ascii strings] table.

[Extended Memory]

This tab use to decide the location of extended memory.



Extended Memory is numbered from EM1 to EM9. Max. size of each extended memory is up to 2G.



External devices such as CF Cards and USB memory sticks are not affected by power loss. Data stored in these locations is retained regardless of HMI power conditions.

If the external device is removed, the "PLC no response" message display when the HMI tries to access extended memory. Data is returned as 0 in this case.

The HMI supports "hot swapping" of CF Card and USB devices. There is no need to interrupt operations to change out CF Card or USB devices.

[Printer Server]

Use this tab to set up all of MT remote printer server setting.

The screenshot shows the 'System Parameter Settings' dialog box with the 'Printer Server' tab selected. The 'Use MT Remote Printer Server' checkbox is checked. The 'Output settings' section includes radio buttons for 'Horizontal' (selected) and 'Vertical', and 'Original size' (selected) and 'Fit to printer margins' for printer size. Margin settings are shown as spinners with a central diagram. The 'Communication settings' section includes text boxes for IP address (0.0.0.0), Port (8005), User name (111111), and password (111111).

Section	Parameter	Value
Output settings	Orientation	Horizontal
	Printer size	Original size
	Margin (Top)	0 mm
	Margin (Bottom)	0 mm
Communication settings	IP address	0 . 0 . 0 . 0
	Port	8005
	User name	111111
	password	111111

<p>Output settings</p>	<p>[Orientation] Picture or word can be set horizontal or vertical.</p> <p>[Printer size] It can be set original size or fit to printer margins.</p> <p>[Margin] The borderline setting include top, bottom, right and left.</p>
<p>Communication settings</p>	<p>[IP address] Assign the IP address of remote printer via network.</p> <p>[Port], [User name], [Password] Determined by user. Port can be set from 1 to 65535. Max. length of user name and password is 12 characters.</p>

※ The other specifics please refer to the appendix Easy Printer.